

WP3: Proton and ion capture


Gabor lens

- The focal length (f) of the Gabor lens:


$$\frac{1}{f} = \frac{e^2 n_e l}{4\epsilon_0 U}$$

where e is electric charge of the electron
 n_e is the plasma density
 l is the length of the plasma
 ϵ_0 is the permittivity of free space
 U is the kinetic energy of the positively charge particle.




- Penning-Malmberg trap



Aymar, G., Becker, T., Boogert, S., Borghesi, M., Bingham, R., Brenner, C., ... & Xiao, R. (2020). LhARA: the laser-hybrid accelerator for radiobiological applications. *Frontiers in Physics*, 8, 567738.





Existing apparatus



Trapping e⁻ plasmas

- Plasma lifetime



- Rotating wall + Cooling gas (CO₂)

April 2024:

Trap potential: -140V

Number of e⁻: 1.7 × 10⁹ electrons

Peak density: 2.3 × 10¹⁴ m⁻³




Radius: ~1.6 mm

September 2024:



Trap potential: -400V

Peak density: ??

Radius: ??



Adjusting the camera iris




Calculating peak density

April 2024:

Trap potential: -140V

Peak density: $2.3 \times 10^{14} \text{ m}^{-3}$

Radius: $\sim 1.6 \text{ mm}$







September 2024:


Trap potential: -400V

Peak density: $1.1 \times 10^{15} \text{ m}^{-3}$

Radius: $\sim 5 \text{ mm}$




Checking E1 output signal



HV trap completely filled with e⁻


Experimental sequence

- 1) Load: 1s
- 2) Hold: 17 μ s
- 3) RW: 14 MHz, 2.95 V_{pp}, 1s
- 4) Dump + Trigger CAM: 5 ms




Experimental sequence


- 1) Load: 1s
- 2) Hold: 17 μ s
- 3) RW: 14 MHz, 2.95 V_{pp}, 1s
- 4) **No Dump** + Trigger CAM: 5 ms



Discussions



Imaging ions in the trap



Conclusion and outlook

Density




- The peak density of the plasma is $1.1 \times 10^{15} \text{ m}^{-3}$.

Radius = 5 mm.

Lifetime = 11 seconds.

Next steps ...

- Image ions in the trap.
- Eliminate the ions
e.g. applying a rotating wall at a frequency resonant with the ions.



WP3 Personnel



W. Bertsche
M. Charlton
S. Eriksson
D. P. van der Werf
C. A. Isaac
C. Baker
P. Ruksasakchai

T. Dascalu
J. Fajans
J. Wurtele
B. Bingham
R. Hugtenburg
J. Purden
A. Knoll
E. Bennet

